

Manufacturer	Type	Stakeholder Comment
Actaris/Schlum/Sangamo/Itron	ACE 1000 SMO	Green fraud light will illuminate, but readings are accurate
Actaris/Schlum/Sangamo/Itron	KBA	Green fraud light will illuminate, but readings are accurate
Actaris/Schlum/Sangamo/Itron	KBB	Green fraud light will illuminate, but readings are accurate
Actaris/Schlum/Sangamo/Itron	KBC	Green fraud light will illuminate, but readings are accurate
Actaris/Schlum/Sangamo/Itron	KBD	Green fraud light will illuminate, but readings are accurate
Actaris/Schlum/Sangamo/Itron	S200.13	Meter requires changing, unless "H" or "h" appears in meter type
Actaris/Schlum/Sangamo/Itron	S200.16	Meter requires changing, unless "H" or "h" appears in meter type
Actaris/Schlum/Sangamo/Itron	S200.28	Meter requires changing, unless "H" or "h" appears in meter type
Actaris/Schlum/Sangamo/Itron	S200.30	Meter requires changing, unless "H" or "h" appears in meter type
Actaris/Schlum/Sangamo/Itron	S200.31	Meter requires changing, unless "H" or "h" appears in meter type
Actaris/Schlum/Sangamo/Itron	S200.32	Meter requires changing, unless "H" or "h" appears in meter type
Actaris/Schlum/Sangamo/Itron	S200.33	Meter requires changing, unless "H" or "h" appears in meter type
Actaris/Schlum/Sangamo/Itron	S200.38	Meter requires changing, unless "H" or "h" appears in meter type
Actaris/Schlum/Sangamo/Itron	S200.4	Meter requires changing, unless "H" or "h" appears in meter type
Actaris/Schlum/Sangamo/Itron	S200.7	Meter requires changing, unless "H" or "h" appears in meter type
Actaris/Schlum/Sangamo/Itron	S204.7	Certification expired - meter requires changing
Actaris/Schlum/Sangamo/Itron	S210	Certification expired - meter requires changing
Actaris/Schlum/Sangamo/Itron	S220	Certification expired - meter requires changing
Actaris/Schlum/Sangamo/Itron	S29.12	Certification expired - meter requires changing
Actaris/Schlum/Sangamo/Itron	S29.13	Certification expired - meter requires changing
Actaris/Schlum/Sangamo/Itron	S29.14	Certification expired - meter requires changing
Actaris/Schlum/Sangamo/Itron	S29.15	Certification expired - meter requires changing
Actaris/Schlum/Sangamo/Itron	S29.2	Certification expired - meter requires changing
Actaris/Schlum/Sangamo/Itron	S29.3	Certification expired - meter requires changing
Actaris/Schlum/Sangamo/Itron	S301.1	Meter requires changing, unless "H" or "h" appears in meter type
Actaris/Schlum/Sangamo/Itron	S301.6	Meter requires changing, unless "H" or "h" appears in meter type
Actaris/Schlum/Sangamo/Itron	S301.9	Meter requires changing, unless "H" or "h" appears in meter type
Actaris/Schlum/Sangamo/Itron	S304	Certification expired - meter requires changing
Actaris/Schlum/Sangamo/Itron	S304.1	Certification expired - meter requires changing
Actaris/Schlum/Sangamo/Itron	S304.10	Certification expired - meter requires changing
Actaris/Schlum/Sangamo/Itron	S304.11	Certification expired - meter requires changing
Actaris/Schlum/Sangamo/Itron	S304.2	Certification expired - meter requires changing
Actaris/Schlum/Sangamo/Itron	S304.4	Certification expired - meter requires changing
Actaris/Schlum/Sangamo/Itron	S304.5	Certification expired - meter requires changing
Actaris/Schlum/Sangamo/Itron	S304.50	Certification expired - meter requires changing
Actaris/Schlum/Sangamo/Itron	S304.51	Certification expired - meter requires changing
Actaris/Schlum/Sangamo/Itron	S304.9	Certification expired - meter requires changing
Actaris/Schlum/Sangamo/Itron	S309.1	Meter requires changing, unless "H" or "h" appears in meter type
Actaris/Schlum/Sangamo/Itron	S309.2	Meter requires changing, unless "H" or "h" appears in meter type
Actaris/Schlum/Sangamo/Itron	S309.3	Meter requires changing, unless "H" or "h" appears in meter type
Actaris/Schlum/Sangamo/Itron	S309.5	Meter requires changing, unless "H" or "h" appears in meter type
AMPY/L+G	5219	5219J - 'rEd' (reverse Energy detected), but readings are accurate
AMPY/L+G	5235	5235A - 'rEd' (reverse Energy detected) but readings are accurate
AMPY/L+G	5235***	5235D-N - 'rEd' (reverse Energy detected), but readings are accurate
AMPY/L+G	5246C-*	'rEd' (reverse Energy detected), but readings are accurate
ARON	el	Certification expired - meter requires changing
ARON	G13	Certification expired - meter requires changing
ARON	G13P	Certification expired - meter requires changing
ARON	G23	Certification expired - meter requires changing
ARON	G23P	Certification expired - meter requires changing
ARON	G24	Certification expired - meter requires changing
ARON	G24P	Certification expired - meter requires changing
ARON	G33	Certification expired - meter requires changing
ARON	G33P	Certification expired - meter requires changing
ARON	G34	Certification expired - meter requires changing
ARON	G34P	Certification expired - meter requires changing
ARON	GM13	Certification expired - meter requires changing
ARON	GM13P	Certification expired - meter requires changing
ARON	GM23	Certification expired - meter requires changing
ARON	GM23P	Certification expired - meter requires changing
ARON	GM24	Certification expired - meter requires changing
ARON	GM24P	Certification expired - meter requires changing
ARON	GM33	Certification expired - meter requires changing
ARON	GM33P	Certification expired - meter requires changing
ARON	GM34	Certification expired - meter requires changing
ARON	GM34P	Certification expired - meter requires changing
ARON	GTM13	Certification expired - meter requires changing
ARON	GTM13P	Certification expired - meter requires changing
ARON	GTM23	Certification expired - meter requires changing
ARON	GTM23P	Certification expired - meter requires changing
ARON	GTM24	Certification expired - meter requires changing
ARON	GTM24P	Certification expired - meter requires changing
ARON	GTM33	Certification expired - meter requires changing
ARON	GTM33P	Certification expired - meter requires changing
ARON	GTM34	Certification expired - meter requires changing
ARON	GTM34P	Certification expired - meter requires changing
ARON	eN	Certification expired - meter requires changing

[illegible]

Manufacturer	Type	Stakeholder Comment
Elster/ABB/GEC/EE	E43B-DR/M	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E43B-R	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E43B-R/M	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E42BC	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E42BC/M	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E42BC-D	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E42BC-D/M	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E42F	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	C11B	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	C11B-R	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	C11B-R/M	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	C11B-D	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	C11B-D/M	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	C11B-DR	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	C11B-DR/M	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E43C-2D	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E43C-2D/M	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E43C-2DR	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E43C-2DR/M	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E42C-2D	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E42C-2D/M	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E42C-2DR	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E42C-2DR/M	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E43F	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E42F-D	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E42F-D/M	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E42F-DR	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E42F-DR/M	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E42F-R	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E42F-R/M	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E43F-D	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E43F-DR	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E43F-R	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	C11B/M	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	C11B2	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	C11B2A	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	C11B2A-R	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	C11B2-R	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	C11B2C	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	C11B2C-R	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	C11B2-D	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	C11B2-DR	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E43B2	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E42B2	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E43B2-D	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E43B2-DR	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E43B2-R	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E42B2-R	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E42B2-D	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E42B2-DR	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E43B3	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E43B3-D	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E43B3-DR	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E43B4	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E43B4-D	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E43B4-DR	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E43F3	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E43F3-D	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E43F3-DR	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E43F4	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E43F4-D	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E43F4-DR	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	E43F4-R	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	C11B3	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	C11B3C	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	J11B	Meter requires changing, unless "H" or "h" appears in meter type
Elster/ABB/GEC/EE	J11D	Meter requires changing, unless "H" or "h" appears in meter type
Horstmann/Secure Controls	NU077-1	'rEd' (reverse Energy detected), but readings are accurate
Horstmann/Secure Controls	NU077-2	'rEd' (reverse Energy detected), but readings are accurate
Horstmann/Secure Controls	J2, K2 and variants	K222 - 'rEd' (reverse Energy detected), but readings are accurate
Horstmann/Secure Controls	K1	K122 - 'rEd' (reverse Energy detected), but readings are accurate
Horstmann/Secure Controls	S1*****	S111 - 'rEd' (reverse Energy detected), but readings are accurate
Horstmann/Secure Controls	Series S	S111 & S123 - 'rEd' (reverse Energy detected), but readings are accurate
Iskra	ME162	Programmable meter which may differ, if configured as 'energy measurement type 4' then they will not increment readings correctly. The energy measurement type character at procurement is the tenth digit in the part number (shown on face-plate) not counting hyphens.
Metropolitan Vickers & AEI	NF5	Meter requires changing

[illegible]

Manufacturer	Type	Stakeholder Comment
Siemens/L+G/FML/Ferranti	F4K-100I-2	Meter requires changing, unless "-9" appears in meter type
Siemens/L+G/FML/Ferranti	F4K-10BI	Meter requires changing, unless "-9" appears in meter type
Siemens/L+G/FML/Ferranti	F4K-10BI-2	Meter requires changing, unless "-9" appears in meter type
Siemens/L+G/FML/Ferranti	F4K-11BI	Meter requires changing, unless "-9" appears in meter type
Siemens/L+G/FML/Ferranti	F4K-11BI-2	Meter requires changing, unless "-9" appears in meter type
Siemens/L+G/FML/Ferranti	F3K-11B	Meter requires changing, unless "-9" appears in meter type
Siemens/L+G/FML/Ferranti	F3K-11B-2	Meter requires changing, unless "-9" appears in meter type
Siemens/L+G/FML/Ferranti	F3K-11BL	Meter requires changing, unless "-9" appears in meter type
Siemens/L+G/FML/Ferranti	F3K-11BL-2	Meter requires changing, unless "-9" appears in meter type
Siemens/L+G/FML/Ferranti	F3K-10B	Meter requires changing, unless "-9" appears in meter type
Siemens/L+G/FML/Ferranti	F3K-10B-2	Meter requires changing, unless "-9" appears in meter type
Siemens/L+G/FML/Ferranti	CM147dk10	Certification expired - meter requires changing
Siemens/L+G/FML/Ferranti	CM147k10	Certification expired - meter requires changing
Siemens/L+G/FML/Ferranti	S2S-600A	Meter requires changing
Siemens/L+G/FML/Ferranti	VL11101	Meter requires changing, unless "H" or "h" appears in meter type
Siemens/L+G/FML/Ferranti	YL11101	Meter requires changing, unless "H" or "h" appears in meter type
Siemens/L+G/FML/Ferranti	ZCB220K	Certification expired - meter requires changing
Siemens/L+G/FML/Ferranti	S2S-601A	Meter requires changing
Siemens/L+G/FML/Ferranti	S2A-100	Programmable meter which may differ, but examples do not increment readings correctly
Siemens/L+G/FML/Ferranti	S2A-200	Programmable meter which may differ, but examples do not increment readings correctly
Siemens/L+G/FML/Ferranti	S2AS	S2AS-100 - Meter requires changing
Siemens/L+G/FML/Ferranti	ZCE 527	'rEd' (reverse Energy detected), but readings are accurate
Smith	AM	Meter requires changing
Smith	APM	Certification expired - meter requires changing
Smith	APNE	Certification expired - meter requires changing
Smith	APNEQ	Certification expired - meter requires changing
Smith	APJ	Certification expired - meter requires changing
Smith	APQ	Certification expired - meter requires changing
Segam	CX1000-3 CLK	Subject to checking - confirm with Meter Operator